

TEAC P-55 / AP-55 / WP-55T RIBBON and CARTRIDGE GUIDE -- Rev. C

Type Of Print You Need

CARTRIDGES You Will Need

RIBBON SET BOXES








VERSAMAX PRINT	VERSAMAX INK CARTRIDGE	TRANSFER CARTRIDGE	VERSAMAX RIBBON
	 <p>* TEAC P/N: CARTRIDGE/VERSAMAX</p>	 <p>TEAC P/N: CARTRIDGE/TFR</p>	 <p>TEAC P/N: VERSAMAX/CMY/SET</p>

PHOTO PRINT	PHOTO/COLOR INK CARTRIDGE	TRANSFER CARTRIDGE	PHOTO RIBBON
	 <p>* TEAC P/N: CARTRIDGE/INK</p>	 <p>TEAC P/N: CARTRIDGE/TFR</p>	 <p>TEAC P/N: PHOTO/RIBBON/SET</p>

COLOR PRINT	PHOTO/COLOR INK CARTRIDGE	TRANSFER CARTRIDGE	COLOR RIBBON
	 <p>* TEAC P/N: CARTRIDGE/INK</p>	 <p>TEAC P/N: CARTRIDGE/TFR</p>	 <p>TEAC P/N: COLOR/RIBBON/SET/A</p>

BLACK PRINT	BLACK INK CARTRIDGE	TRANSFER CARTRIDGE	TWO SEPARATE RIBBONS ARE NEEDED	
	 <p>* TEAC P/N: CARTRIDGE/BLK</p>	 <p>TEAC P/N: CARTRIDGE/TFR</p>	 <p>P/N: BLACK/RIBBON</p>	 <p>TRANSFER/RIBBON/A</p>

* As of Jan. 2009, The P55 printer includes the VersaMax and Transfer cartridges. The Photo/Color and Black Cartridges are sold separately.