





# TEAC P-55 / AP-55 / WP-55T RIBBON and CARTRIDGE GUIDE -- Rev. C

Type Of Print You Need






CARTRIDGES You Will Need

RIBBON SET BOXES

<b>VERSAMAX PRINT</b>	VERSAMAX INK CARTRIDGE	TRANSFER CARTRIDGE	VERSAMAX RIBBON
	 <p>* TEAC P/N: <b>CARTRIDGE/VERSAMAX</b></p>	 <p>TEAC P/N: <b>CARTRIDGE/TFR</b></p>	 <p>TEAC P/N: <b>VERSAMAX/CMY/SET</b></p>

<b>PHOTO PRINT</b>	PHOTO/COLOR INK CARTRIDGE	TRANSFER CARTRIDGE	PHOTO RIBBON
	 <p>* TEAC P/N: <b>CARTRIDGE/INK</b></p>	 <p>TEAC P/N: <b>CARTRIDGE/TFR</b></p>	 <p>TEAC P/N: <b>PHOTO/RIBBON/SET</b></p>

<b>COLOR PRINT</b>	PHOTO/COLOR INK CARTRIDGE	TRANSFER CARTRIDGE	COLOR RIBBON
	 <p>* TEAC P/N: <b>CARTRIDGE/INK</b></p>	 <p>TEAC P/N: <b>CARTRIDGE/TFR</b></p>	 <p>TEAC P/N: <b>COLOR/RIBBON/SET/A</b></p>

<b>BLACK PRINT</b>	BLACK INK CARTRIDGE	TRANSFER CARTRIDGE	<b>TWO SEPARATE RIBBONS ARE NEEDED</b>	
	 <p>* TEAC P/N: <b>CARTRIDGE/BLK</b></p>	 <p>TEAC P/N: <b>CARTRIDGE/TFR</b></p>	 <p>P/N: <b>BLACK/RIBBON</b></p>	 <p><b>TRANSFER/RIBBON/A</b></p>

\* As of Jan. 2009, The P55 printer includes the VersaMax and Transfer cartridges. The Photo/Color and Black Cartridges are sold separately.