

Important Information:

- SxS memory card is shipped from factory in FAT format.
- Please install the latest SxS device driver when using the SxS memory cards with Windows PC/Mac. For the detailed information, please visit the following URL: <http://www.sony.net/SxS-Support>
- For XDCAM/XDCAM EX device firmware updates, please check the website of each product.
- When using SxS memory card which is formatted in different file system from device's file system, it should be formatted with device in advance. **In case any contents have been recorded in the SxS memory card, please make a backup copy before formatting.**

	SxS-1			SxS PRO			SxS PRO+			
	SBS-32G1*1	SBS-32G1A SBS-64G1A	SBP-6 SBP-16	SBP-32	SBP-64A	SBP-64B	SBP-128B	SBP-64C	SBP-128C	
PMW-EX1	✓ Requires firmware update v1.20 or higher for hardware.	✓ Requires firmware update v1.25 or higher for hardware.	✓	✓ The firmware of hardware is required to update to version 1.20 or higher.	✓ Requires firmware update v1.25 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	
PMW-100	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-160	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-200	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-EX3	✓ Requires firmware update v1.10 or higher for hardware.	✓ Requires firmware update v1.15 or higher for hardware.	✓	✓	✓ Requires firmware update v1.15 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	
PMW-EX30	✓ Requires firmware update v1.20 or higher for hardware.	✓ Requires firmware update v1.20 or higher for hardware.	✓	✓	✓ Requires firmware update v1.20 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	
PMW-EX1R	✓	✓ Requires firmware update v1.15 or higher for hardware.	✓	✓	✓ Requires firmware update v1.15 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	
PMW-350	✓	✓ Requires firmware update v1.15 or higher for hardware.	✓	✓	✓ Requires firmware update v1.15 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	
PMW-320	✓	✓	✓	✓	✓	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.3 or higher for hardware.	
PMW-F3	✓	✓	✓	✓	✓	✓ Requires firmware update v1.3 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	✓ Requires firmware update v1.4 or higher for hardware.	
PMW-F5	✓ ⁹⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁶⁾	✓ ⁹⁾	✓ ⁶⁾	✓ ⁶⁾	✓	✓	✓	✓	
PMW-F55	✓ ⁹⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁶⁾	✓ ⁹⁾	✓ ⁶⁾	✓ ⁶⁾	✓	✓	✓	✓	
PMW-500	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	
PMW-400	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-300	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-EX280	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-150	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-EX160	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PMW-EX260	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PXW-X160	✓ ⁶⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓	✓	✓	✓	
PXW-X180	✓ ⁶⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓	✓	✓	✓	
PXW-X200	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓	✓	✓	✓	
PXW-X500	✓ ⁶⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓ ⁶⁾	✓	✓	✓	✓	
PMW-TD300	✓	✓	✓	✓	✓	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	
PDW-HR1 with PDBK-MK1	✓ Media firmware upgrade is required to use in MXF mode.	✓	✓	✓	✓	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	
XDS-1000	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	
XDS-PD1000	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	
XDS-PD2000	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.0 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	✓ ⁴⁾ ✓ ⁵⁾ Requires firmware update v2.4 or higher for hardware.	
PMW-50	✓ ⁴⁾ Media firmware upgrade is required to use in MXF mode.	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	✓ ⁴⁾	
PMW-10MD	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓	✓	✓	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	✓ Requires firmware update v1.2 or higher for hardware.	
PMW-1000	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾	✓ ⁸⁾ Requires firmware update v1.1 or higher for hardware.	✓ ⁸⁾ Requires firmware update v1.1 or higher for hardware.	
PMW-RX50	✓	✓	✓	✓	✓	✓	✓	✓	✓	
PXU-MS240	✓ ²⁾	✓ ²⁾ Requires firmware update v1.11 or higher for hardware.	✓ ²⁾	✓ ²⁾	✓ ²⁾	✓ ²⁾ Requires firmware update v1.11 or higher for hardware.	×	×	Not applicable	
SBAC-US10	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	
SBAC-US20	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾ ✓ ⁷⁾	✓ ³⁾ ✓ ⁷⁾	
SBAC-US30	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	✓ ³⁾	

- Remarks:**
- *1. Media firmware update may be required. For detailed information, please check the website of each product.
 - *2. "UDF formatted" or "exFAT formatted" SxS memory cards cannot be used.
 - *3. To use "UDF formatted" SxS memory cards with Windows PC/Mac, SxS UDF Driver needs to be installed. For detailed information, please check the website of each product.
 - *4. When copying the content from SxS memory card to internal storage, FAT/UDF can be automatically detected.
 - *5. For "UDF formatted" SxS memory cards, recording to memory cards is not supported. For "FAT formatted" SxS memory cards, recording to memory cards (including copying), deleting clips, and formatting memory cards are not supported.
 - *6. Recording in 4k XAVC, SxP and some other modes are not supported.
 - *7. The SBAC-US20 firmware update is required. Please check the website of product.
 - *8. For "FAT formatted" SxS memory cards, recording to memory cards (including copying), deleting clips, and formatting memory cards are not supported.
 - *9. The operation is not guaranteed.